



Taylor Made  
PRODUCTS™

# T-top Bow Shade Instructions

**This Shade is designed to only be in place on your boat when anchored or at drift. NEVER leave this product up and assembled on your boat when underway!**

**No tools required for quick and easy installation:**

Simply unfold the T-top Bow Shade and orient with widest section towards T-top. Disconnect the quick release buckles around the shade and fully extend the webbing straps. Wrap the two center straps around the T-top front frame section. Connect the buckles and pull straps to tighten. Working around the shade, wrap around and connect the webbing straps to convenient locations on the bow rails and pull to tighten. Once all adjustable straps are in place, it may be necessary to readjust the straps to center and properly tighten the T-Top Bow Shade.

**Taylor Made Products**

65 Harrison Street

Gloversville, NY 12078

*A Member of The Taylor Made Group*

[www.taylormadeproducts.com](http://www.taylormadeproducts.com)

©Taylor Made is a registered trademark of the Nelson A. Taylor Co., Inc.

**ADDITIONAL WARRANTY INFORMATION**

TAYLOR MAKES NO EXPRESS OR IMPLIED WARRANTIES OTHER THAN WARRANTIES SET FORTH HEREIN, INCLUDING, WITHOUT LIMITATION, THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR FROM ANY COURSE OF DEALING OR TRADE USAGE.

TAYLOR SHALL NOT BE LIABLE FOR SPECIAL, INDIRECT, INCIDENTAL, PUNITIVE OR CONSEQUENTIAL DAMAGES, INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF OPPORTUNITY OR BUSINESS PROFITS, BUSINESS INTERRUPTION OR ANY OTHER LOSS EVEN IF TAYLOR HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

IN NO EVENT SHALL TAYLOR BE LIABLE FOR ANY AMOUNT IN EXCESS OF THE PURCHASE PRICE PAID.